

ON LINE INSTRUCTIONS
for the build of your
NORTHERN FINE SCALE KIT

Go to www:northernfinescale.com

Click “ENTER”

Click “ Kit Instructions”

Then click the kit required.

You will see that the Peak Wagon and Cattle Wagon kits have yet to be listed

PEAK ROOF WAGON

Assemble the wagon following for the 9ft wheel base wagon instructions.

Remove runner pips from side of roof panel

Ensure that the angled edge is at the top.

Hold roof panels in place on the wagon and glue centre seam.

Butt the two capping strips together at the peak of the roof.

Glue and trim ends

Glue roof to wagon

Before the roof is fitted we advise that you add weight to the wagon by fixing a block of wood inside the wagon.

CATTLE WAGON

Follow the Van instructions.

Add the bars to the openings in the sides before fixing the roof.

We advise that you add some weight to the wagon, in the form of a metal strip fixed to the underside of the floor or a cattle load.

Contact Peter Armstrong 01425-276587 or email northernfinescale@talktalk.net if you have any comments or queries.