



PUSH PULL COACH

With a small fine file shape the 3 lamp irons. Using glue and the 1/32 rivets fix lamp irons to the front of the coach as shown in photo.

Glue the 3 steps large one at the top as shown in the photo.

Fit grab handle to coach front & sides. Grab handles marked F fit above the windows on the front.

Fit the window wiper to driver's window.

Head code disc fits on lamp irons.

Cut the vacuum pipe and fit as shown in photo.

The driver (not supplied) is a modified railway man from P.S People.